



Installation Instructions

1. Form a 4 inch round hole in the drain board by placing a wood board behind the drain board. Then set metal punch on front of drain board and strike metal punch with a small sledgehammer until the punch cuts through the drain board. Or a standard utility knife may also be used to cut the hole in the drain board.
2. Insert drainage collector through back of drain board.
3. Place All-Purpose Cement on the portion of drainage collector that extends through drain board and attach retainer ring. Hand squeeze retainer ring to drainage collector to form a seal with drain board until cement sets (about 10 seconds).
4. Place All-Purpose Cements on inside of portion of drainage collector that extends through drain board and attach 3 inch diameter PVC pipe (not included).